

QUICK START GUIDE





FB50C Plus FB50CS Plus



WHAT'S IN THE BOX





Mouse




USB Type-C Charging Cable



5-Level DPI Adjustable

KNOW YOUR PRODUCT





CONNECTING 2.4G DEVICE







Plug the receiver into






connected. **CONNECTING BLUETOOTH**

EVICE 1 (For Mobile Phone/Tablet/Laptop) Blue Light



(≱1)





2


BLUETOOTH DEVICE



Bluetooth

FB50C Plus Connected (i

DEVICES





BLUETOOTH DEVICE



0

(\$2)







FB50C Plus c








 Θ

C EF© FRE



USB-C

Buttons No.: 7

Weight: 79 g

Receiver: Nano Receiver

Charging Cable: 60 cm Size: 120 x 63 x 36 mm

System: Windows / Mac / iOS / Chrome

⑤ 2H Charing Time

Flashing Red light indicates when the battery is below 25%.

TECH SPEC

USB-A 0

Up to 3 Devices: Bluetooth x 2, 2.4GHz x 1 Sensor: Optical

Distance: 5~10 m Style: Symmetric

Report Rate: 125 Hz

Connection: Bluetooth / 2.4GHz



3)

Q & A Question How many devices can be connected in total? Answer Interchange and connect up to 3 devices at the same time. 2 Devices with Bluetooth +1 Device with 2.4G Hz.

Resolution: 1000-1200-1600-2000-3200 DPI

/ Android / Harmony OS...

Question How to switch connected Bluetooth devices? (Answer) Repeat the procedure of connecting Bluetooth devices.

Question Does the mouse remember connected devices after power off?

Answer The mouse will automatically remember and connect last device. You may switch the devices as you choose to.

Question How do I know what device is currently connected to? (Answer) When the power is turned on, the indicator light will be displayed for 10S.

WARNING STATEMENT

1. To disassemble, bump, crush, or throwing into fire, you may cause irrefutable

damages in event of the lithium battery leakage. 2. Do not expose under the strong sunlight.

3. Please obey all local laws when discarding the batteries, if possible please recycle it. Do not dispose it as household garbage, it may cause a fire or an explosion.

4. Please try to avoid charging in the environment below 0°C. 5. Do not remove or replace the battery. 6. Forbidden to use 6V to 24V charger, otherwise the product will be burned.

The following actions may/will cause damages to the product.

Recommended to use a 5V charger for charging.





