




www.a4tech.com

Product Features



www.a4tech.com

Package Including



Keyboard



User Manual

www.a4tech.com



FSTYLER LOW PROFILE SCISSOR SWITCH KEYBOARD QUICK START GUIDE

FX50

www.a4tech.com

Windows/Mac OS Keyboard Layout

System	Shortcut [Short Press for 1S]	Indicator Light
Windows		 Scroll Lock Flashing Off
Mac OS		


Note: Windows is default system layout. The device will remember the last keyboard layout, please switch as needed.

FN Multimedia Key Combination Switch

FN Mode: You can lock & unlock FN mode by short pressing FN + ESC by turn.



- ① Lock Fn Mode: No need to press FN key
 - ② Unlock Fn Mode: FN + ESC
- ※ After pairing, FN shortcut is locked in FN mode by default, and the locking FN is memorized when switching and shutting down.



www.a4tech.com

Other FN Shortcuts Switch

Shortcuts	win (Windows)	mac (Mac OS)
	Brightness +	Brightness +
	Brightness -	Brightness -
	Scroll Lock	Not Support

Note: The final function refer to the actual system.

Dual-Function Key

Shortcuts	win (Windows)	mac (Mac OS)
	Switching Steps: ① Choose Windows layout by pressing win. ② Choose Mac OS layout by pressing mac.	
	Ctrl	Control ⌘
	Start	Option ⌥
	Alt	Command ⌘
	Alt (Right)	Command ⌘
	Ctrl (Right)	Option ⌥

www.a4tech.com

Product Specifications

Model: FX50

Switch: Scissor Switch

Actuation Point: 1.8 ± 0.3 mm

Keycaps: Chocolate Style

Character: Silk Printing + UV

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 - F12

Report Rate: 125 Hz

Cable Length: 150 cm

Port: USB

Includes: Keyboard, User Manual

System Platform: Windows / Mac

www.a4tech.com

Q & A

Question Can the keyboard support Mac platforms?

Answer Support: Windows | Mac keyboard layout switching.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.

www.a4tech.com