



FSTYLER LOW PROFILE SCISSOR SWITCH KEYBOARD

QUICK START GUIDE

FX53

www.a4tech.com

Keyboard

USB Type-C Cable

User Manual

Product Features

- 12 Multimedia & Internet Hotkeys
- Operating System Swap
- PC/MAC Dual-Function Keys
- Function Indicator

www.a4tech.com

Low Profile Scissor Switch Keyboard

Revolutionary Anti-Ghosting

Note: Supports Windows OS Only

Multi-key rollover ensures smooth typing and precise multi-key input, eliminating key conflicts for efficient workflows and competitive gameplay.

* 5-Key Rollover

* 5-Key Rollover

* 9-Key Rollover

* Multi-Key Rollover

www.a4tech.com

Low Profile Scissor Switch Keyboard

Windows/Mac OS Keyboard Layout

System	Shortcut [Long-Press for 3S]	Function / Layout Indicator
Mac	fn + O <small>mac</small>	Light will be off after flashing.
Windows	fn + P <small>win</small>	

Note: The layout you used last time will be remembered.
You can switch the layout by following the above step.

FN Multimedia Key Combination Switch

fn + **F1** home Home Page

F5 input Input Switching

F9 next Next Track

F2 sys System Switching

F6 cap Screen Capture

F10 mute Mute

F3 back Backward

F7 prev Previous Track

F11 vol- Volume Down

F4 search Search

F8 play Play / Pause

F12 vol+ Volume Up

www.a4tech.com

Low Profile Scissor Switch Keyboard

Other FN Shortcuts Switch

Shortcuts	Windows	Mac
fn + enter	Scroll Lock	
fn + insert	Pause	
fn + ▲	Device Screen Brightness +	
fn + ▼	Device Screen Brightness -	

Note: The final function refer to the actual system.

Dual-Function Key

Keyboard Layout	Windows	Mac
fn + O <small>mac</small> P <small>win</small>	Switching Steps: ① Choose MAC layout by pressing Fn+O ② Choose Windows layout by pressing Fn+P .	
ctrl <small>^</small>	Ctrl	Control <small>^</small>
opt <small>⌘</small>	Start	Option
alt <small>cmd</small> alt <small>cmd</small> alt <small>cmd</small>	Alt	Command
alt <small>cmd</small> alt <small>cmd</small>	Alt (Right)	Command
ctrl <small>opt</small> ctrl <small>opt</small>	Ctrl (Right)	Option

www.a4tech.com

Low Profile Scissor Switch Keyboard

Product Specifications

Model: FX53

Switch: Scissor Switch

Character: Laser Engraving

Total Travel Distance: 2.0 mm

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 ~ F12

Report Rate: 125 Hz

Cable Length: 150 cm

Port: USB

Includes: Keyboard, USB Type-C Cable, User Manual

System Platform: Windows / Mac

www.a4tech.com

Low Profile Scissor Switch Keyboard

Q & A

Question How to switch layout under different system?

Answer You can switch layout by pressing Fn + O / P under Windows | Mac.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.

www.a4tech.com



www.a4tech.com



Scan for E-Manual