





SCISSOR SWITCH KEYBOARD **QUICK START GUIDE**

FX55

www.a4tech.comQ

(Package Including)

Low Profile Scissor Switch Keyboard

Low Profile Scissor Switch Keyboard




Keyboard



USB Type-C Cable



User Manual



Note: Supports Windows OS Only

Multi-key rollover ensures smooth typing and precise multi-key input, eliminating key conflicts for efficient workflows and competitive gameplay.

* 5-Key Rollover

TSTYLER_


(Revolutionary Anti-Ghosting)

Copy lick. A S D F G H J K L UNIT O Z X C V B N M

> * 9-Key Rollover * 5-Key Rollover * Multi-Key Rollover

etrl optic

• • •



www.a4tech.com

Shortcut [Long-Press for 3S]

(FN Multimedia Key Combination Switch)

COLLECTION

System

Mac

Windows

fn + (F1 A) Home Page

Shortcuts

fn + 📤

Keyboard Layout

ctrl

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 ~ F12

Report Rate: 125 Hz

Cable Length: 150 cm

Includes: Keyboard, USB Type-C Cable, User Manual

System Platform: Windows / Mac

Port: USB

Note: The final function refer to the actual system.

Note: The layout you used last time will be remembered. You can switch the layout by following the above step.

Low Profile Scissor Switch Keyboard

Mac

Low Profile Scissor Switch Keyboard

Function / Layout Indicator

Light will be off after flashing.

(F9 → Next Track



Windows

Windows

Start ==

Ctrl

Device Screen Brightness +

Device Screen Brightness -


Switching Steps:
① Choose MAC layout by pressing Fn+O
② Choose Windows layout by pressing Fn+P.

Control ^

Option ~

Low Profile Scissor Switch Keyboard

cmd ₩	Alt	Command **
alt cmd ₩	Alt (Right)	Command 🥞
ctrl opt √	Ctrl (Right)	Option 🗨
COLLECTION	Low Profile Scissor Switch Keyboard	



(Q & A)Question How to switch layout under different system? You can switch layout by pressing Fn + O / P Answer under Windows | Mac.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.



FSTYLER. COLLECTION

www.a4tech.com



EST. 1987