




FSTYLER LOW PROFILE SCISSOR SWITCH KEYBOARD

QUICK START GUIDE

FX70

www.a4tech.com

Package Including




Keyboard



User Manual

Product Features




- 1 Integrated Stand Cradle
- 2 12 Multimedia & Internet Hotkeys
- 3 Operating System Swap
- 4 PC/MAC Dual-Function Keys
- 5 Function Indicator

www.a4tech.com

Revolutionary Anti-Ghosting

Note: Supports Windows OS Only

Multi-key rollover ensures smooth typing and precise multi-key input, eliminating key conflicts for efficient workflows and competitive gameplay.



- * 5-Key Rollover
- * 5-Key Rollover
- * 9-Key Rollover
- * Multi-Key Rollover

www.a4tech.com

Windows/Mac OS Keyboard Layout

System	Shortcut [Long-Press for 3S]	Function / Layout Indicator
Mac	fn + O _{mac}	Light will be off after flashing.
Windows	fn + P _{win}	

Note: The layout you used last time will be remembered.
You can switch the layout by following the above step.

FN Multimedia Key Combination Switch

- fn** + **F1**_{ph} Home Page
- F5** Input Switching
- F9** Next Track
- F2**_{bit} System Switching
- F6**_{ch} Screen Capture
- F10** Mute
- F3**_{tr} Backward
- F7**₄₄ Previous Track
- F11** Volume Down
- F4**_Q Search
- F8** Play / Pause
- F12** Volume Up

www.a4tech.com

Other FN Shortcuts Switch

Shortcuts	Windows	Mac
fn + FSTYLER	Menu	
fn + ▲	Device Screen Brightness +	
fn + ▼	Device Screen Brightness -	

Note: The final function refer to the actual system.

Dual-Function Key

Keyboard Layout	Windows	Mac
fn + O _{mac} P _{win}	Switching Steps: ① Choose MAC layout by pressing Fn+O . ② Choose Windows layout by pressing Fn+P .	
ctrl ^	Ctrl	Control ^
opt ⌘	Start ⬢	Option ⌘
alt ⌘	Alt	Command ⌘
alt ⌘	Alt (Right)	Command ⌘
ctrl ⌘	Ctrl (Right)	Option ⌘

www.a4tech.com

Installation

Connection

Plug the USB cable to the computer USB port.

Software Download

For the best product performance, please download and install the Software from www.a4tech.com/download.aspx

Note: The software does not support Mac systems.



www.a4tech.com

Product Specifications

- Switch:** Scissor Switch
- Character:** Laser Engraving
- Total Travel Distance:** 2.0 mm
- Keyboard Layout:** Win / Mac
- Hotkeys:** FN + F1 ~ F12
- Report Rate:** 1000 Hz
- Cable Length:** 150 cm
- Port:** USB
- Includes:** Keyboard, User Manual
- System Platform:** Windows / Mac

Q & A

Question How to switch layout under different system?

Answer You can switch layout by pressing **Fn + O / P** under Windows | Mac.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.

www.a4tech.com